



Your window motor will arrive with the plug end of the wire disconnected. You will need to test fit the wires to find the correct pairing, this may be black to black, or red to black.

Test this by running the built up regulator outside the door to ensure pulling the switch 'up' makes the window go 'up' and not down.

Once tested, crimp as required.

